

User's Manual


Medium Power Jammer

Thank you for purchasing the Cellular Jammer. Please first read this manual completely before using this device, save this manual and keep it handy.

GENERAL

This device utilizes unique technic that interfere the communication between cellular handset and cellular base station by low power radio signals. The effective range is up to 15 meters radius, depending on the strength and type of cellular

PRINCIPLE PARTS



INSTALLATION

1. Connect the AC adaptor with electricity, and plug another side into the socket located at the rear end of right bottom side (from the front view)
2. Install this device in vertical at the height about 2.0 meters will get the best jamming result.
3. Check this device in different positions by dialing the cellular phone to test and find the best interfering position of the Jammer".
4. If install several sets of this Jammer in a same place of bigger area, it will have better results if install the Jammers in diagonal places.
5. Upon activating the Jammer, all the cellular phone calls already in connection inside the jamming area will be cut-off in 10 - 40 seconds and the radio link will be lost. All the cellular phones in the jamming area will become idle and indicate "No Service" or "No Network" or "Blank receiving status" on its screen. Or the indication appears as usual, but cannot dial. After the Jammer is activated, all the incoming calls will be handled as if the cellular phone is OFF and the incoming calls may be routed into the voice mailbox.

NOTICE OF USE

1. Removal of cover or broken seal will void all warranties.
2. Install the Jammer in vertical at height about 2.0 meters will get better Jamming result.
3. For better performance, use this device in an individual space (room). This device is not able to cover different spaces (rooms) divided with walls. Install individual Jammer in different partition of a building to ensure the best jamming result.

SPECIFICATION

Power	5V DC, 2A switching power adaptor
Effective range	Up to 15 meters radius, depending on the strength and type of cellular system
Dimension	L 98 x W 85 x H 245 mm
Weight	650 g

- Specifications may change without notice

NOTICE OF INSTALLATION

The effective range of this device depends on the type of cellular system (network). Different installations will cause big different results. For example, there are two kinds of installation as follows for your reference.

1. Install the jammer near the window and dial the mobile phone inside the office.
2. Install the jammer inside the office, and dial the mobile phone near the window.

Normally, the first kind of installation will cover bigger area. Because the jammer blocks the signals from outside. If you know the direction of nearby base station, then install the jammer in that direction will get better jamming results. Besides, the indoor base station signal strength in higher floor will be higher than lower floor, because there is less attenuation to the base station.

COPYRIGHT

No part of this manual may be reproduced, transmitted, transcribed, or translated into any language in any form by any means, electrical or mechanical, including photocopying, recording, or information and retrieval systems, without the express written permission of manufacturer. Products mentioned in this manual are for identification purposes only. All brand names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies. The manufacturer reserves the right to change or modify the specifications of any one or all of these products as deemed necessary at any time without prior notification. The manufacturer may further revise this manual from time to time without prior notice.